



COPPER CLEANING INSTRUCTIONS

OUR PREMIUM COPPER FIRE BOWLS COME PRE PATINA'D. THIS PATINA BEING A LIVING FINISH WILL DARKEN OVER TIME. IF THE COPPER IS EXPOSED TO POOL CHEMICALS THAN BLUE/GREEN SPOTS WILL RESULT. SOME CUSTOMERS LIKE THIS LOOK, IF YOU DO NOT HERE ARE SOME SIMPLE CLEANING INSTRUCTIONS TO RESTORE YOUR FIRE BOWLS ORIGINAL LOOK.

TOOLS REQUIRED:

- 1) 000 STEEL WOOL
- 2) 500 OR 600 GRIT BLACK WET SAND PAPER
- 3) DISH SOAP
- 4) PREMIER SURFACE WAX
- 5) CLEAN CLOTH
- 6) WATER HOSE

INSTRUCTIONS:

- 1) MIX DISH SOAP AND WATER IN A BUCKET
- 2) CLEAN THE OUTSIDE OF THE FIRE BOWL USING THE 000 STEEL WOOL AND SOAPY WATER.
- 3) WET YOUR 5-600 GRIT SAND PAPER AND LIGHTLY SAND THE BOWL.
- 4) AFTER SANDING, RINSE THE BOWL WITH CLEAN WATER. MAKE SURE TO SPRAY YOUR DECKING CLEAN TO PREVENT ANY STAINING.
- 5) SPRAY THE BOWLS WITH "PREMIER SURFACE WAX" AND WIPE WITH A CLEAN CLOTH.
- 6) MAINTAIN THE FIRE BOWL USING THE WAX AS NEEDED.

